



Zenderfrequenties Multicast

Fréquences de chaînes Multicast

Televisiezenders

Chaînes de télévision

Zender/Chaîne	Multicast Broadcast	Multicast Fiber
één HD	239.232.209.112	239.232.209.112
Canvas HD	239.232.209.113	239.232.209.113
Ketnet	239.232.209.123	239.232.209.123
VIER HD	239.232.209.21	239.232.209.21
VIJF HD	239.232.209.26	239.232.209.26
vtm HD	239.232.209.126	239.232.209.126
Q2 HD	239.232.209.54	239.232.209.54
CAZ	239.232.209.92	239.232.209.92
Vitaya	239.232.209.58	239.232.209.58
KanaalZ	239.232.209.132	239.232.209.132
Actua TV	239.232.209.76	239.232.209.76
Play Time HD	239.232.209.45	239.232.209.45
DOBBIT TV	239.232.209.48	239.232.209.48
PlattelandsTV	239.232.209.57	239.232.209.57
Brava	239.232.209.7	239.232.209.7
ZES HD	239.232.209.93	239.232.209.93
La Une HD	239.232.209.29	239.232.209.29
La Deux HD	239.232.209.30	239.232.209.30
La Trois	239.232.209.148	239.232.209.148
Arte Belgique	239.232.209.13	239.232.209.13
AB3	239.232.209.10	239.232.209.10
RTL TVI HD	239.232.209.31	239.232.209.31
Plug RTL	239.232.209.41	239.232.209.41
NPO 1	239.232.209.36	239.232.209.36
NPO 2	239.232.209.37	239.232.209.37
NPO 3	239.232.209.38	239.232.209.38
TF1 HD	239.232.209.55	239.232.209.55
France 2	239.232.209.24	239.232.209.24
France 3	239.232.209.25	239.232.209.25
ARD	239.232.209.12	239.232.209.12
ZDF	239.232.209.56	239.232.209.56
BBC1	239.232.209.14	239.232.209.14
BBC2	239.232.209.15	239.232.209.15
BBC World	239.232.209.16	239.232.209.16
TV5 Monde	239.232.209.106	239.232.209.106
TVE	239.232.209.53	239.232.209.53
Rai Uno	239.232.209.42	239.232.209.42
BBC Entertainment	239.232.209.111	239.232.209.111
TRT Turk	239.232.209.52	239.232.209.52
2M Monde	239.232.209.81	239.232.209.81
Al Maghreb TV	239.232.209.46	239.232.209.46
Al Jazeera Eng.	239.232.209.127	239.232.209.127
Russia Today	239.232.209.222	239.232.209.222
CNN	239.232.209.19	239.232.209.19
Euronews	239.232.209.22	239.232.209.22
Bloomberg	239.232.209.128	239.232.209.128
CCTV	239.232.209.89	239.232.209.89



Zenderfrequenties Multicast

Fréquences de chaînes Multicast

Televisiezenders

Chaînes de télévision

Zender/Chaîne	Multicast Broadcast	Multicast Fiber
Eurosport HD	239.232.209.79	239.232.209.79
Extreme Sport	239.232.209.225	239.232.209.225
Eurosport 2 HD	239.232.209.130	239.232.209.130
njam!	239.232.209.77	239.232.209.77
Nat Geo HD	39.232.209.35	Voorlopig niet beschikbaar
Sundance TV	239.232.209.82	239.232.209.82
Sundance TV FR	239.232.209.86	239.232.209.86
vtmKzoom	239.232.209.135	239.232.209.135
Studio 100 TV	239.232.209.114	239.232.209.114
Nickelodeon/Spike HD	239.232.209.34	239.232.209.34
Nick Jr.	239.232.209.139	239.232.209.139
Cartoon Network	239.232.209.87	239.232.209.87
MTV	239.232.209.232	239.232.209.232
Kadet	239.232.209.9	239.232.209.9
Comedy Central	239.232.209.8	239.232.209.8
MENT TV	239.232.209.231	239.232.209.231
R. Contact Vision	239.232.209.216	239.232.209.216
Club RTL HD	239.232.209.40	239.232.209.40

Regionale zenders

Chaînes régionales

Zender/Chaîne	Multicast Broadcast	Multicast Fiber
ATV	239.232.223.66	239.232.223.66
AVS Gent	239.232.223.64	239.232.223.64
AVS Oudenaar.	239.232.223.65	239.232.223.65
TV Limburg	239.232.223.61	239.232.223.61
RTV Mechelen	239.232.223.71	239.232.223.71
RTV Turnhout	239.232.223.72	239.232.223.72
WTV	239.232.223.73	239.232.223.73
AVS Eeklo	239.232.223.63	239.232.223.63
TV Oost Dend.	239.232.223.62	239.232.223.62
RTV Geel	239.232.223.69	239.232.223.69
TV Oost StNik.	239.232.223.62	239.232.223.62
Focus	239.232.223.78	239.232.223.78
Ring-TV	239.232.223.67	239.232.223.67
RTV Herentho.	239.232.223.70	239.232.223.70
BRUZZ	239.232.223.60	239.232.223.60
notélé	239.232.223.39	239.232.223.39
ROB	239.232.223.68	239.232.223.68
BXI	239.232.223.83	239.232.223.83



Zenderfrequenties Multicast

Fréquences de chaînes Multicast

Play Sports

Play Sports

Zender/Chaîne	Multicast Broadcast	Multicast Fiber
Play Sports HD1	239.232.210.227	239.232.210.227
Play Sports HD2	239.232.210.228	239.232.210.228
Play Sports HD3	239.232.210.229	239.232.210.229
Play Sports HD4	239.232.210.230	239.232.210.230
Play Sports HD5	239.232.210.236	239.232.210.236
Play Sports HD6	239.232.210.243	239.232.210.243
Play Sports HD7	239.232.210.244	239.232.210.244
Play Sports HD8	239.232.210.245	239.232.210.245
Play Sports GOLF	239.232.210.223	239.232.210.223
Eleven	239.232.210.246	Voorlopig niet beschikbaar
Eleven Sports	239.232.210.247	Voorlopig niet beschikbaar

Radiozenders

Chaînes radio

Zender/Chaîne	Multicast Broadcast	Multicast Fiber
Radio 1	239.232.223.171	239.232.223.171
Radio 2 Vl. Br.	239.232.223.172	239.232.223.172
Radio 2 Antw.	239.232.223.173	239.232.223.173
Radio 2 Limb.	239.232.223.174	239.232.223.174
Radio 2 O. Vl.	239.232.223.175	239.232.223.175
Radio 2 W. Vl.	239.232.223.176	239.232.223.176
StuBru	239.232.223.178	239.232.223.178
MNM	239.232.223.179	239.232.223.179
Klara	239.232.223.177	239.232.223.177
Sporza	239.232.223.180	239.232.223.180
Klara Continuo	239.232.223.182	239.232.223.182
MNM Hits	239.232.223.183	239.232.223.183
VRT NWS	239.232.223.184	239.232.223.184
JOE fm	239.232.223.161	239.232.223.161
Q-music radio	239.232.223.170	239.232.223.170
Mint	239.232.223.191	239.232.223.191
Contact	239.232.223.192	239.232.223.192
Nostalgie	239.232.223.213	239.232.223.213
Bel RTL	239.232.223.190	239.232.223.190
MC Dancefloor Fillers	239.232.223.203	239.232.223.203
MC Freedom	239.232.223.204	239.232.223.204
MC Headbangers	239.232.223.205	239.232.223.205
MC Jazz Classics	239.232.223.206	239.232.223.206
MC Chillout	239.232.223.207	239.232.223.207
MC 70s	239.232.223.208	239.232.223.208



Zenderfrequenties Multicast

Fréquences de chaînes Multicast

Radiozenders

Chaînes radio

Zender/Chaîne	Multicast Broadcast	Multicast Fiber
MC Reggae Vibra	239.232.223.209	239.232.223.209
MC Rock Anthems	239.232.223.210	239.232.223.210
MC Rock Alternative	239.232.223.211	239.232.223.211
MC Total Hits - UK	239.232.223.212	239.232.223.212
La Première	239.232.223.185	239.232.223.185
Radio Maria	239.232.209.214	239.232.209.214